



INSTALLATION INSTRUCTIONS

- 1) DRILL AND FILL HOLE WITH QUICK DRY CEMENT.
- 2) PUSH STOP INTO HOLE AND LET IT DRY.

