



1. Mount approximately 54" above floor or per specified ada.
2. Mark and mount Arm Base to door frame. Note: Position base so that base edge is 1/8" from edge of frame.
3. Position and mount base on door 7/16" from edge of arm base.

